

# LOADWEIGH™ M350S user & quick setup guide



Firmware version 4D.01.16


Power-up the display by either switching on the ignition (ignition live wiring) or press the power button beneath the logo (where fitted) if the indicator is permanently wired to the vehicle supply.



to switch ON turn ignition and/or press logo




**Welcome screen**  
appears for 10 seconds



**Service and calibration due screen**  
appears for 5 seconds

## MENU screen



- A Alarm graphic - shows both alarms.
- B Alarm set key
- C Print key - prints net, gross, time & date in weighing screens
- D Menu key - scrolls thru' NET, GROSS & MENU screens
- E Service reminder, flashes when weigher service is due
- F OK key - enters data
- G Down arrow key - scrolls down menu
- H Up arrow key - scrolls up menu
- I Back Up key - goes back a step

Press menu key to scroll up and down menu screens

**MENU**  
selectable options

M E N U  
Display Diagnostics Configuration  
Alarms Calibration  
Options Alarms System

---

**NET**  
total load in body note, zero will appear +/- 500 kg to mute alarm press any key

15950 kg net  
print zero menu

---

**GROSS**  
total truck weight note, zero will appear +/- 500 kg

31950 kg gross  
print tare menu

---

**MENU with options activated**

**LOAD**  
When LOAD is activated, amount collected in one container from one site

140 kg load  
On site zero menu

---

**TOTAL**  
When LOAD is activated, total collected from different containers from one site

540 kg total  
print zero menu

---

**SPLIT SCREEN**  
Shows channel 1 ( e.g. front) and channel 2 (e.g. rear or separate hopper)

4770 kg Channel 1 7450 kg Channel 2  
menu

---

**INCLINOMETER**  
Where activated and calibrated: Circles fill for each degree of body list left or right.

net 15950 kg inc  
○○○○○○○●○○○○○○○ menu

Note  
**GROSS** or GVW (gross vehicle weight) is the total truck weight (NET + TARE)  
**NET** 'net load' means the payload weight in the truck body  
**LOAD** means part load collected or delivered, press PRINT to print and zero the load, weight collected is stored as an accumulation to NET  
**SPAN** where used, means the NET weight used to calibrate the weigher  
**TARE** weight means the weight of the empty vehicle  
**ALARM** where fitted, an alarm sounder flashing beacon will activate when alarm setpoint is reached  
**ON SITE** when 'load' is turned on in options, on site allows logging onto site and off site for weighing loads collected from a site with multiple bins (waste only)

**Display** Changes OLED contrast to high, medium or low. Also shows info: version & serial no.

**Diagnostics** Engineers screen. Shows two channel weights and input milli-volt signals

**Alarms** Two alarm setpoints - PIN code required  
To mute Alarm - press any key

**Options** Modes: Switches GROSS on & off  
Load: On or off  
RS232: Printer or scoreboard mode  
Count by: 1, 10, 20, 50, 100, & 200 kgs  
Z/Func: Allow/inhibit keyboard zero

**Configuration** To select 1 or 2 channels, air, oil or fifth wheel.  
Split: For split axle systems. Option for total Ch1 + Ch2 or separate Ch1 & Ch2 calibrations

**Calibration** Weighing system calibration settings

**System** Accesses password set and resets.  
Note. for PUK (PIN unlock code) contact service who will take you through your PIN retrieval. Edit time and date in system.

**SALES**  
Vehicle Weighing Solutions  
Unit 5, Southview Park, Marsack Street,  
Caversham, Reading RG4 5AF  
T: 0118 948 4908  
F: 0118 946 1862

**INSTALLATIONS**  
Vehicle Weighing Solutions  
Hyde Road, off Foxdenton Lane,  
Chadderton, Oldham M24 1QG  
T: 0161 643 0202  
F: 0161 643 2239

**INSTALLATIONS**  
Vehicle Weighing Solutions  
Unit 4a Sheepbridge Business Centre  
Sheepbridge lane, CHESTERFIELD S41 9RX  
Tel: 01246 455 946


need help? call  
**0161 643 0202**  
info@vwsLtd.co.uk  
www.vwsLtd.co.uk

# CALIBRATION AND SET UP - follow these five steps

## STEP 1 ENTERING PIN CODE


- 1 In MENU screen select SYSTEM press **OK**
- 2 Press **▼** key to select PIN:
- 3 Press **OK** to display PIN input screen
- 4 Press **▼** & Keys to number. Press **←** to move cursor left
- 5 When PIN is entered press **→** to enter code
- 6 Press **OK** to accept PIN
- 7 Press **←** to back up to MENU
- 8 To Set PIN, select PIN **OK** repeat 2 - 6

Note. PIN is needed for every calibration change  
PIN can be reset to a new code of your choice. If PIN is lost call Service.




## STEP 2 SET THE VEHICLE TARE WEIGHT

- 1 Ensure vehicle is empty, weigh & record TARE (kerb empty) weight
- 2 In MENU screen select CALIBRATION press **OK**
- 3 Select TARE press **OK** (defaults to 10000)
- 4 Press **▼**
- 5 Enter the vehicle TARE (empty weight) as in stage 1
- 6 When done press **→**
- 7 Press **←** to return to MENU screen



## STEP 3 SET THE ZERO (EMPTY) CALIBRATION

- 1 If the vehicle is a tipper, raise the body clear of the chassis
- 2 In CAL menu Press **▼** to select Zero
- 3 Press **OK**
- 4 Press **cal** key
- 5 Press **OK** to confirm channel 1 Zero CAL
- 6 Press **←** to return to CAL menu



Reverse ZERO/SPAN  
The reverse zero/span is used to do a simultaneous zero and span calibration. Allows span calibration when the truck is full before zero calibration. You must be in single channel mode, ch1 only. See technical bulletin: M3505 - Version 01-11 Update - M3505 v01-11

engineer info only

## STEP 4 FULL SPAN (NET LOAD) CALIBRATION

- 1 Load vehicle to its legal maximum, weigh & record GROSS weight
- 2 Subtract the TARE (or KERB) weight from the GROSS weight to give the SPAN (NET) weight. E.g. 31900 kg GROSS - 12500 kg, TARE = 19400 kg SPAN (NET) PAYLOAD
- 3 If the vehicle is a tipper, raise the body clear of the chassis
- 4 In CAL menu Press **▼** to select Span
- 5 Press **OK** (defaults to 22680 kg)
- 6 Press **▼**
- 7 Edit the SPAN (NET) PAYLOAD weight, as in STEPS 1 & 2 above press **→** when done
- 8 Press **cal** to enter CAL. Press **OK** to confirm
- 9 Press **←** twice to return to MENU screen




engineer info only

engineer info only

## STEP 5 ALARM SETPOINTS (pin code required, see step one above)

- 1 In MENU, select ALARMS. Two setpoints appear, select 'Alarm 1'
- 2 Press 'OK' to toggle between 'ON' or 'OFF', select 'ON'
- 3 Select 'Output' Invert or Normal (see note)
- 4 Select: 'Gross-Sounder', 'Net-Sounder', 'Gross-PPCO' or 'Net-PPCO'
- 5 Select 'Alm' alarm will activate at this weight. Press 'Edit' and enter target weight setpoint using techniques in previous steps.
- 6 'Hys' Hysterisis (see note) edit in kg
- 7 'Trigger' select- OFF, 2 seconds, 5 seconds or 10 seconds (see note)
- 8 When all settings are correct press **→** to input settings
- 9 For alarm 2, select a'Alarm 2' and repeat STEP 5



Note.

Output: Normal = +12 vdc to power an alarm, output invert = -12 vdc to deactivate (a packer)

PPCO: PackerPlate cut-off, refuse trucks only

HYS: Is hysteresis and gives the option to activate the alarm in a window range above and below the alarm setpoint (an alarm reset tolerance)

Trigger: This is a selectable delay prior to alarm activation